

- 2) Not for construction.
- 3) Expansion tank must be located after check valve.
- 4) Locate injection tee in last storage tank

